

Disclaimer

Safety Symbols

Safety Instructions

Regulatory Compliance

Appendix

What's in the Box

Technical Specification

Product Compatibility List



1	Recess Handle	Used for safely lifting and moving the device.
2	Protective Cover	Used for shielding electrical terminals and outlets from dust, moisture, and accidental contact.
3	Grounding Terminal	Used for providing a supplemental ground connection.



4	DIY Front Case	Used for maintaining the original appearance. DIY replacement cases are available for purchase.
5	Power Button	Used for turning the device on or off and resetting IoT settings.
6	System Status LED	Used for indicating the current operating status of the device.



7	AC Outlet †	When the device is on-grid, the outlet can be used for supplying power to connected appliances, connecting to a microinverter to add extra power input, or connecting in parallel with another STREAM device.
8	Grid Terminal	Used for connecting the device to the utility grid or for paralleling with another unit.
9	PV Terminals	Used for connecting solar panels for power input.



† The actual appearance of the AC outlet may vary by sales region and product version.

Control Button

Power Button

The button serves the following functions:

- **Power On:** Press and hold the button for 2 seconds to turn on the device.
- **Power Off:** Press and hold the button for 2 seconds to turn off the device. If solar or grid power is present, disconnect the cables before powering off.
- **Reset IoT:** Press the button 5 times in quick succession to reset Wi-Fi and Bluetooth connections.



Resetting the IoT settings will unbind the device from your EcoFlow account.



LED Indicator

System Status LED


The following LED pattern indicates that the device is powered off.




The following LED pattern indicates the current battery level of the device.




The following LED pattern indicates that the device is being charged.



The following LED pattern indicates that the device is faulty. Check the EcoFlow app for further instructions.



The following LED pattern indicates that a setting has been applied, such as a system reset or the completion of internet setup.



The following LED pattern indicates that the device is upgrading its firmware.

